

SOLARLINK FR360

Self-Powered Digital AM/FM, NOAA Weather Radio
with Flashlight, Solar Power and Cell Phone Charger



NEED HELP? CONTACT US.

Eton Corporation, 1015 Corporation Way, Palo Alto, CA 94303, USA. 1-800-872-2228 (U.S.); 1-800-637-1648 (Canada); 650-903-3866 (worldwide); M-F, 8:30-4:00, Pacific Standard Time; www.etoncorp.com.

WARNING

- Do not expose this appliance to rain or moisture.
- Do not submerge or expose for extended period to water.
- Protect from high humidity and rain.
- Only operate within specified temperature range (0 °C to 40 °C).
- Unplug immediately if liquid has been spilled or any object has fallen into the apparatus
- Clean only with a dry cloth. Do not use detergents or chemical solvents as this might damage the finish.
- Unplug and disconnect external antennas during lightning storms.
- Do not remove cover [or back].
- Refer servicing to qualified service personnel.

ENVIRONMENT

Disposal

According to the European Directive 2002/96/EC all electrical and electronic products must be collected separately by a local collection system. Please act according to your local rules and do not dispose of your old products with your normal household waste.



The FR360 plays AM (520-1710 KHz), FM (87.5-108 MHz) and 7 NOAA Weather Channels:

Channel 1	162.400 MHz
Channel 2	162.425 MHz
Channel 3	162.450 MHz
Channel 4	162.475 MHz
Channel 5	162.500 MHz
Channel 6	162.525 MHz
Channel 7	162.550 MHz

For best results read the instructions below.

VOLUME CONTROL

Turning the Volume Adjusting Knob (located on the lower left) clockwise turns up the volume; counterclockwise turns down the volume. Always turn down the volume before using earphones.

TURNING THE FR360 ON/OFF

The FR360 is powered with 3 AA batteries, the Dynamo and Solar cell (DYN/SOL) and the AC adapter (not included). To turn the radio on, select DYN/SOL or BATT (upper right, next to the LCD) and then press POWER.

Note: the radio can be played while it's charging.

BATTERY POWER

Install 3 AA batteries and set the power selector switch to the BATT position.

SOLAR POWER

When you're in sunlight set the power switch to the DYN/SOLAR position. This position also recharges the Ni-MH rechargeable battery.

DYNAMO POWER

The rechargeable Ni-MH (nickel-metal-hydride) battery is in the battery compartment. To use it plug the battery into the socket adjacent to it, then

set the power switch to the DYN/SOL position. You may have to charge the battery; to do this turn the crank for 90 seconds. The rechargeable battery will eventually lose its ability to hold a charge. Call Eton Corporation to order another one.

DC-IN 5V AC ADAPTER (not included)

This is the first socket to the left on the back of the radio, under the rubber plugs. Plug in the AC adapter (not included) to the DC IN 5 volt socket. This also charges the Ni-MH battery.

ANSWERS TO QUESTIONS REGARDING CHARGING

- How much operating time does 90 seconds of hand cranking provide for the radio to play? About 15 minutes.
- How long does it take to fully charge the radio's battery with the AC adapter? About 2 hours.
- How long will the radio play when charged with the AC adapter? About 10hrs.
- How long does it take to fully charge the radio's battery with the solar panel? About 10 hrs in direct sunlight.

CHARGING CELL PHONES

Press the button labeled CELL. Plug the cell phone charging cord into the USB PHONE CHARGER jack, the second socket from the left at the rear of the radio. Plug the other end of the cord into the jack of the cell phone. About 10 minutes of cranking results in one or two short emergency calls.

THE LIGHT ABOVE THE CRANK

A red light means radio is on. A green light means that there is sufficient crank speed to enable a charge.

LCD BACKLIGHT

Press the DISP button to turn on the backlight for the LCD and the buttons above the LCD for 5 seconds, after which it turns off.

SELECTING BANDS AND TUNING IN STATIONS

The FR360 plays AM (520-1710 KHz), FM (87.5-108 MHz) and 7 NOAA

Weather Channels:

Turn the radio on. Select AM, FM or WB1-WB7 with the knob above the TUNE button (right side of the radio).

When listening to FM and Weather channels, pull up the telescopic antenna all the way. When tuning AM stations the telescopic antenna is not needed and can be lowered. Tune in stations by revolving the TUNE knob (right side of the radio).

The weather frequencies are on channels WB1 through WB7. Try all of them and find the one that's strongest; the strongest one is your weather station. The frequencies associated with them are:

WB1; Channel 1	162.400 MHz
WB2; Channel 2	162.425 MHz
WB3; Channel 3	162.450 MHz
WB4; Channel 4	162.475 MHz
WB5; Channel 5	162.500 MHz
WB6; Channel 6	162.525 MHz
WB7; Channel 7	162.550 MHz

THE NOAA ALERT FEATURE

After you have tuned in your local Weather channel, the radio can be set to the ALERT function, by pressing the ALERT button (far right above the LCD). This function turns off the radio, but continues to monitor the NOAA frequency. If an alert is broadcast, it turns back on, enabling you to hear the alert broadcast. To turn ALERT off, press ALERT again; ALERT disappears from the display.

NOTE: while ALERT is selected, no other stations can be tuned in or received.

SETTING THE TIME AND ALARM

The clock is a 12/24-hour clock, showing PM in the display starting at Noon. To change from 12 to 24 hour time or vice versa:

1. With the radio turned off, do three short presses of the SET button.
2. 12 or 24 appears in the display.
3. Press the MIN/UP or HOUR/DOWN buttons to change it.
4. Press SET to finalize it.

To set the time:

1. With the radio turned off, do a short press on the SET button.
2. While the hour flashes press the HR/UP or MIN/DOWN button to set the hour.
3. Press SET again.
4. While the minute flashes press the HR/UP or MIN/DOWN button to set the minutes.
5. Press SET to finalize

To set the alarm:

1. With the radio turned off, press the ALARM button and then the SET button.
2. ALARM appears on the left of the LCD and the hour flashes.
3. Press HR/UP or MIN/DOWN button to set the alarm hour.
4. Press SET again.
5. While the minute flashes press the HR/UP or MIN/DOWN button to set the alarm minutes.
6. Press SET to finalize.

TURNING THE ALARM ON AND OFF

With the radio on or off press the ALARM ON/OFF button. Notice that when it's on, ALARM appears in left of the LCD.

SLEEP FEATURE

The sleep timer can be activated with the radio turned on or off. Activating the sleep timer enables the radio to play for 90, 60, 30 and 10 minutes, then shut off automatically.

To activate it press the SLEEP button (in the upper right, above the display) until the minutes you want it to play appear, then stop pressing. SLEEP appears to the left in the display and the radio plays for the selected minutes, then stops.

EARPHONE JACK

Located on the back of the radio, the third socket from the left. Plug in any stereo earphones. Audio is heard in mono only. Always turn down the volume when plugging in earphone/headphones, then turn it up.

AUDIO-IN JACK

Located on the back of the radio, the fourth socket from the left, it enables you to listen to other devices, such as an iPod, using a stereo 3.5 mm (1/8 inch) cord to connected to it.

WARRANTY REGISTRATION

To ensure full warranty coverage or product updates, registration of your product should be completed as soon as possible after purchase or receipt. You may use one of the following options to register your product:

1. By visiting our website at <http://www.etoncorp.com>.
2. Mail in enclosed warranty card.
3. Mail your registration card or information to following address; include your name, full mailing address, phone number, email address, model purchased, date purchased, retail vendor name:

Etón Corporation

1015 Corporation Way
Palo Alto, CA 94303 USA

LIMITED WARRANTY

Retain the warranty information from your warranty card with your proof of purchase or the Limited Warranty information can also be viewed at www.etoncorp.com.

SERVICE FOR YOUR PRODUCT

To obtain service for your product, we recommend first contacting an Etón service representative at 1-800-872-2228 US, 1-800-637-1648 Canada, (650) 903-3866 US, customersvc@etoncorp.com or your respective country distributor in Europe (see enclosed list) for problem determination and trouble-shooting. If further service is required, the technical staff will instruct how to proceed based on whether the radio is still under warranty or needs non-warranty service.

WARRANTY – If your product is still in warranty and the Etón service representative determines warranty service is needed, a return authorization will be issued and instructions will be given. DO NOT ship your radio back without obtaining the return authorization.

NON-WARRANTY – If your product is no longer under warranty and requires service, the Etón service representative will refer you to the nearest repair facility that will best handle the repair.

For service outside North America, please refer to the distributor information included at time of purchase/receipt.



Etón Corporation


Corporate Headquarters
1015 Corporation Way
Palo Alto, California 94303 USA
tel +1 650-903-3866
tel +1 800-872-2228
fax +1 650-903-3867

Etón Canada

1 Yonge Street, Suite 1801
Toronto, Ontario M5E 1W7 Canada
tel +1 416-214-6885

! READ THIS FIRST

The rechargeable NiMh battery has been disconnected for transportation purposes. To use the crank-charge system, open the battery compartment and connect the rechargeable battery's plug into its socket, as per the diagram below:



? QUESTIONS

Etón Corporation
1015 Corporation Way
Palo Alto, CA 94303, USA

1.800.872.2228 U.S.
1.800.637.1648 Canada
1.650.903.3866 World-Wide
www.etoncorp.com
customersvc@etoncorp.com

*Denotes Required Field

Etón Product Registration

Go to: **www.etoncorp.com/productregistration**, or mail this form today.

Cell Phone Model #*:

Serial number*:
(located in the back of the unit)

Date of purchase*:

Dealers name*:

City*:

Country/Territory*:

Name*: First Name | Last Name

Address*:

City*:

State/Province*:

Postal Code/ZIP Code*:

Country/Territory*:

Telephone Number*: Day Phone | Evening Phone

Email*:

1. Your annual income?

- | | |
|--|---|
| <input type="radio"/> Under \$14,999 | <input type="radio"/> \$50,001 to \$75,000 |
| <input type="radio"/> \$15,000 to \$30,000 | <input type="radio"/> \$75,001 to \$150,000 |
| <input type="radio"/> \$30,001 to \$50,000 | <input type="radio"/> Over \$150,001 |

2. Your age?

- | | | |
|--------------------------------|-----------------------------|-----------------------------------|
| <input type="radio"/> Under 16 | <input type="radio"/> 31-35 | <input type="radio"/> 51-55 |
| <input type="radio"/> 16-20 | <input type="radio"/> 36-40 | <input type="radio"/> 56-60 |
| <input type="radio"/> 21-25 | <input type="radio"/> 41-45 | <input type="radio"/> 61 and over |
| <input type="radio"/> 26-30 | <input type="radio"/> 46-50 | |

3. What are your listening interests? (Check all that apply)

- | | |
|---------------------------------------|---|
| <input type="radio"/> Satellite Radio | <input type="radio"/> Shortwave/International Broadcast |
| <input type="radio"/> Local AM/FM | |

4. Did you consider another unit before choosing this product?

- ☐ Yes (Please Specify Model): _____
- ☐ No

5. What is your occupation? _____

6. How did you hear about Etón?

- | | |
|--|-----------------------------------|
| <input type="radio"/> Newspaper ad | <input type="radio"/> Article |
| <input type="radio"/> Radio ad | <input type="radio"/> Web Search |
| <input type="radio"/> Through a retailer | <input type="radio"/> Other _____ |

- ☐ **Yes!** I would like Etón to send me information on products including special offers, new product launches, and product updates/information:

- ☐ Email ☐ Mail

etón
re_inventing radio
www.etoncorp.com

Standard of Quality

Limited Warranty and Product Registration

USA

Etón Corporation

Corporate Headquarters
1015 Corporation Way
Palo Alto, CA 94303

www.etoncorp.com

Canada

Etón Electronics Canada LTD

Toronto Office
1 Yonge Street, Suite 1801
Toronto, Ontario M5E 1W7

www.etoncorp.com

etón
re_inventing radio
www.etoncorp.com

GARANTIEBESTIMMUNGEN

Etón Corporation (Etón) bietet Kunden auf das original erworbene Produkt eine beschränkte Garantie auf Herstellungsmängel bei Material und Verarbeitung. Diese Garantie ist ausschließlich für den Originalkunden gültig und nicht übertragbar.

2 (zwei) Jahr auf Bauteile und Arbeit - Europe

1 (ein) Jahr auf Bauteile und Arbeit - North America

Diese beschränkte Garantie beginnt ab Datum der Originalkaufrechnung und gilt ausschließlich für Produkte, die bei autorisierten Etón Vertriebshändlern erworben wurden. Reparaturen unter den Garantiebestimmungen dürfen nur durch Etón oder einen autorisierten Kundendienst erfolgen. Im Reparaturfall während der Garantie ist auf Nachfrage die Originalkaufrechnung bzw. eine Kopie als Kaufnachweis vorzulegen. Installation, Abbau und Wiederaufbau des Produkts fallen nicht unter die Garantie. Für den Versand an Etón oder einen autorisierten Kundendienst trägt der Käufer die Verantwortung. In Europa erworbene Produkte bitte bei Ihrem Händler oder dem Generalvertreter in Ihrem Land einreichen. Ein Verzeichnis mit Adressen ist der Verpackung beigelegt.

Werden während der Garantiezeit Mängel festgestellt, repariert Etón kostenlos und nach eigenem Ermessen das Produkt mit neuen oder überholten Teilen bzw. tauscht diese aus. Um den Garantieanspruch nicht zu verwirken, muss das Produkt spätestens 15 Tage nach Ablauf der Garantiezeit ausreichend frankiert an Etón oder den zuständigen Kundendienst eingereicht werden. Vor einer Rücksendung des Produkts zwecks Garantieleistungen hat der Käufer sich mit Etón oder dem zuständigen Kundendienst in Verbindung zu setzen, damit Fehlerbehebungsmaßnahmen

besprochen werden können und er Anweisungen bezüglich der Serviceverfahren erhält. Mangelhafte Teile oder Produkte sind dann Eigentum von Etón. Für durch Etón ausgetauschte Teile und Produkte gilt die verbleibende reguläre Garantiezeit bzw. eine Garantiezeit von 90 (neunzig) Tagen, je nachdem welcher Zeitraum länger ist.

Die beschränkte Garantie deckt Herstellungsfehler bei Material und Verarbeitung, die bei normalem, nicht gewerblichem Betrieb dieses Produkts auftreten. Nicht gedeckt ist u. a. Folgendes: Schäden, die aufgrund von zweckentfremdeter Anwendung und Gebrauch des Geräts auftreten; Fehler oder Probleme, die durch Produkte oder Ausstattung verursacht werden, die nicht durch Etón geliefert wurden; Unfälle, falsche und unzulässige Benutzung, Unterlassung, falsche Anwendung, Feuer-, Wasser-, Blitz- oder sonstige Natureinwirkungen; falsche Eingangsspannung, Spannungsschwankungen und -spitzen; Schäden durch falsche oder unvorschriftsmäßige Installation; Schäden durch Säureaustritt aufgrund von unvorschriftsmäßig eingelegten Batterien bzw. von schadhaften Batterien; Änderungen oder Modifikationen am Produkt; oder die Verwendung von nicht autorisierten Teilen, Verbrauchsmaterialien, Zubehörteilen oder Ausstattungen, die dieses Produkt beschädigen oder Betriebsstörungen verursachen.

Kundendienst

Wir empfehlen, sich zur Fehlerbehebung zuerst an einen Kundendienstmitarbeiter von Etón oder Ihren Generalvertreter des jeweiligen Landes zu wenden. Sie erreichen uns unter 1-800-872-2228 (USA) oder 1-800-637-1648 (Kanada) bzw. über das beigelegte Händlerverzeichnis (Europa). Oftmals können die üblichen Fragen und kleine Probleme bereits am Telefon gelöst und behoben werden.

GARANTIE LIMITÉE

Etón Corporation (Etón) offre une garantie limitée au client initial pour tous les défauts de fabrication concernant le matériel et la qualité de ce produit. Cette garantie n'a de valeur que pour le client d'origine et n'est pas cessible.

GARANTIE DE (2) AN SUR LES PIÈCES ET LA MAIN D'ŒUVRE - Europe

GARANTIE DE (1) AN SUR LES PIÈCES ET LA MAIN D'ŒUVRE - North America

Cette garantie limitée démarre à compter de la date initiale de l'achat et s'applique uniquement aux produits achetés auprès d'un vendeur Etón agréé. Les réparations de garantie doivent être effectuées par Etón ou un centre de services agréé. Pour bénéficier des services de garantie, le bon d'achat initial daté ou sa copie doit être présenté sur demande en tant que preuve d'achat. L'installation, le démontage ou la réinstallation du produit ne sont pas inclus dans cette garantie. La responsabilité de l'envoi du produit à Etón ou au centre de services agréé incombe au client. Pour les produits achetés en Europe, veuillez les retourner à votre vendeur ou au revendeur de votre pays mentionné dans la liste ci-jointe à cet emballage.

Etón réparera ou remplacera ce produit, à notre choix et sans aucun frais, avec des pièces neuves ou remises en état si nous constatons que ce produit est défectueux au cours de la durée de garantie limitée. Pour bénéficier de la couverture de garantie, le produit doit être retourné à Etón ou au centre de services désigné au plus tard dans les 15 jours suivant l'expiration de la durée de garantie, frais d'envoi payés. Avant de renvoyer tout produit en vue de bénéficier d'un service de garantie, le client

doit contacter Etón ou le centre de services désigné pour le dépannage et les instructions relatives au service de garantie. Les pièces ou les produits endommagés deviendront la propriété d'Etón. Les pièces et les produits remplacés par Etón bénéficient de la garantie initiale restante ou de quatre-vingt-dix (90) jours, selon la période la plus longue.

Cette garantie limitée couvre les défauts de fabrication concernant le matériel et la qualité survenus au cours d'une utilisation normale et non commerciale de ce produit et ne s'applique pas aux dommages suivants : dommages survenus après une utilisation et un usage pour lequel le produit n'est pas conçu ; défauts ou problèmes causés par des produits ou des appareils n'ayant pas été fournis par Etón ; accidents, mauvaise utilisation, abus, négligence, mauvais usage, feu, eau, foudre ou toute autre influence naturelle ; tension électrique incorrecte voltage, fluctuations ou surtensions ; dommages causés par une installation impropre ou erronée ; dommages causés par une fuite d'acide due à des piles défectueuses ou mal installées ; vieillissement ou modification du produit ; utilisation de pièces, de dispositifs électriques, d'accessoires ou d'équipement non agréés qui endommagent ce produit ou entraînent des problèmes liés au service de garantie.

INFORMATIONS RELATIVES AU SERVICE DE GARANTIE

Pour bénéficier d'un service de garantie pour votre produit, nous vous conseillons de contacter en premier lieu un représentant du service de garantie Etón au 1-800-872-2228 pour les États-Unis, 1-800-637-1648 pour le Canada ou le revendeur dans votre pays en Europe (voir liste ci-jointe) qui vous dépannera. De nombreuses questions et les problèmes d'ordre général peuvent être résolus par téléphone.

GARANTÍA LIMITADA

Etón Corporation (Etón) otorga una garantía limitada al cliente original para fallos de fabricación en el material y la elaboración de este producto. Esta garantía es válida exclusivamente para el comprador original y no se puede transferir.

DOS (2) AÑO PARA PIEZAS Y TRABAJO - Europe UN (1) AÑO PARA PIEZAS Y TRABAJO - North America

El período de esta garantía limitada empieza con el día de la compra y resulta vigente sólo para productos comprados con un distribuidor autorizado de Etón. Las reparaciones sujetas a garantía deben realizarse por parte de Etón o bien un centro de servicio autorizado. Para solicitar un servicio de garantía, debe presentarse el comprobante original de compra con fecha o bien una copia, como prueba de la adquisición realizada. Esta garantía no abarca la instalación, el retiro o la reinstalación del producto. El transporte a Etón o bien al centro de servicio autorizado se realiza bajo responsabilidad del comprador. Para productos comprados en Europa, solicitamos contactar el distribuidor correspondiente en su país que se encuentra indicado en la lista que se encuentra dentro del embalaje.

Etón procede con la reparación o el reemplazo de este producto, a decisión de la compañía y sin cargo alguno, mediante aplicación de piezas nuevas o reacondicionadas en caso que el producto resultase defectuoso durante el período limitado de garantía. Para asegurar la aptitud para la cobertura de garantía, el producto debe devolverse a Etón o a un centro de servicio designado a más tardar 15 días después de la expiración del período de garantía, con los costes de transporte pagado previamente.

GARANZIA LIMITATA

Etón Corporation (Etón) offre una garanzia limitata ai propri clienti per eventuali difetti dei materiali e di produzione. Tale garanzia è valida esclusivamente nei confronti dell'acquirente originario e non è trasferibile.

DEU (2) ANNO DI GARANZIA PER RICAMBI E MANODOPERA - Europe UN (1) ANNO DI GARANZIA PER RICAMBI E MANODOPERA - North America

La garanzia limitata ha validità a partire dalla data di acquisto e riguarda esclusivamente i prodotti acquistati presso un rivenditore Etón. Gli interventi in garanzia devono essere eseguiti da Etón o da un centro di assistenza autorizzato. Per accedere al servizio in garanzia sarà necessario presentare, su richiesta, la ricevuta con la data di acquisto o una copia di essa, a conferma dell'acquisto. L'installazione, la rimozione o la reinstallazione del prodotto non sono coperte dalla presente garanzia. La spedizione del prodotto a Etón o al centro di assistenza autorizzato avviene sotto la responsabilità dell'acquirente. Per i prodotti acquistati in Europa si prega di fare riferimento al proprio rivenditore o al distributore del proprio paese, inserito nell'elenco allegato all'imballaggio.

Etón provvederà a riparare o a sostituire il prodotto, a propria discrezione e senza alcuna spesa per l'acquirente, con pezzi di ricambio nuovi o rigenerati, qualora vengano riscontrati difetti nel prodotto nel periodo di validità della garanzia limitata. Per ottenere il servizio previsto dalla garanzia, il prodotto deve essere restituito a Etón o al centro di assistenza indicato, entro 15 giorni dalla data di scadenza della garanzia, con spese di spedizione pagate. Prima di restituire il prodotto per

Antes de la devolución del producto para solicitar algún servicio de garantía, el comprador debe contactar a Etón o el centro de servicio designado para la localización y resolución del problema, así como para las instrucciones relacionadas al procedimiento de servicio. Las piezas o los productos dañados quedarán en manos de Etón. Las piezas y los productos reemplazados por Etón se incorporan en la garantía original restante, o bien obtienen una garantía de noventa (90) días, dependiendo del plazo que resulta mayor.

Esta garantía limitada cubre los fallos de fabricación en material y elaboración detectados durante el uso normal y no comercial de este producto. No se aplica, sin restringirse en las indicaciones, en lo siguiente: daños relacionados con aplicaciones o utilidades para las cuales el producto no ha sido diseñado; fallos o problemas causados debido a productos o equipos no suministrados por Etón; accidentes, uso incorrecto, abuso, negligencia, mala aplicación, fuego, agua, relámpagos u otros actos de naturaleza; voltaje de línea, fluctuaciones o fusibles incorrectos; daños causados por una instalación incorrecta o defectuosa; daños causados por una fuga de ácido de baterías instaladas de manera incorrecta o defectuosa; la alteración o modificación del producto; o bien el uso de piezas, suministros, accesorios o equipos sin autorización y que dañan este producto o que generan problemas de servicio.

INFORMACIÓN DE SERVICIO

Para solicitar algún servicio para su producto Etón, le recomendamos contactar primero al representante de servicio de Etón llamando al número de teléfono 1-800-872-2228 para los EE.UU., o al número de teléfono 1-800-637-1648 para Canadá o bien su distribuidor respectivo del país dentro de Europa (véase la lista adjunta) para la localización y resolución del problema. La mayor cantidad de preguntas y problemas puede solucionarse a través del teléfono.

L'intervento in garanzia, l'acquirente dovrà contattate Etón o il centro di assistenza indicato per ricevere istruzioni circa l'individuazione e la risoluzione dei problemi e le procedure di assistenza. I componenti o i prodotti danneggiati divengono di proprietà di Etón. I componenti e i prodotti sostituiti da Etón saranno garantiti per il rimanente periodo della garanzia originaria e in ogni caso per non meno di novanta (90) giorni.

La presente garanzia limitata copre i difetti di produzione e dei materiali riscontrati durante il normale impiego, non commerciale, del prodotto e non si applica nei seguenti casi: danni causati da applicazioni e usi diversi da quelli previsti per il prodotto; guasti o problemi causati da prodotti o attrezzature non fornite da Etón; danni causati da incidenti, uso improprio, negligenza, applicazioni errate, incendi, acqua, fulmini o altri eventi naturali; danni causati da tensione di linea errata, sbalzi o picchi di corrente; danni causati da installazione errata o imperfetta; danni causati da fuoriuscite di acido da batterie installate scorrettamente o da batterie difettose; modifiche apportate al prodotto; utilizzo di pezzi di ricambio, accessori e componenti non autorizzati o attrezzature che danneggiano il prodotto o comportano la necessità di riparazioni.

INFORMAZIONI PER L'ASSISTENZA

Per ottenere assistenza per il prodotto Etón da voi acquistato, contattare il servizio clienti Etón al numero 1-800-872-2228 USA, 1-800-637-1648 Canada o il distributore locale in Europa (vedere l'elenco allegato) per l'individuazione e risoluzione dei problemi. Molti dei problemi più comuni possono essere risolti telefonicamente.

LIMITED WARRANTY

Etón Corporation (Etón) offers a limited warranty to the original customer against manufacturing defects in material and workmanship on this product. This warranty is valid only for the original purchaser and is not transferable.

TWO (2) YEARS PARTS AND LABOR - Europe ONE (1) YEAR PARTS AND LABOR - North America

This limited warranty begins on the original date of purchase, and is valid only on products purchased through an authorized Etón retailer. Warranty repairs must be performed by Etón or an authorized service center. To receive warranty service, the original dated bill of sale, or a copy, must be presented upon request as proof of purchase. Installation, removal or reinstallation of the product is not included under this warranty. Shipping to Etón or the authorized service center is the responsibility of the purchaser. For products purchased in Europe, please return to your dealer or the distributor of your country, which is listed on a sheet included in the packaging.

Etón will repair or replace this product, at our option and at no charge, with new or reconditioned parts if this product is found to be defective during the limited warranty period. To be eligible for warranty coverage, the product must be returned with shipping charges prepaid no later than 15 days after the expiration of the warranty period to Etón or the designated service center. Prior to

returning any product for warranty service, the purchaser must contact Etón or the designated service center for troubleshooting and service procedure instructions. Damaged parts or products become the property of Etón. Parts and products replaced by Etón assume the remaining original warranty, or ninety (90) days, whichever is longer.

This limited warranty covers manufacturing defects in material and workmanship encountered in normal, noncommercial use of this product and shall not apply to the following, including, but not limited to: damage that occurs due to applications and uses for which the product was not intended; failures or problems that are caused by products or equipment not supplied by Etón; accidents, misuse, abuse, neglect, misapplication, fire, water, lightning, or other acts of nature; incorrect line voltage, fluctuations, or surges; damage caused by improper or faulty installation; damage caused by acid leakage from improperly installed or defective batteries; product alteration or modification; or use of unauthorized parts, supplies, accessories, or equipment that damage this product or result in service problems.

SERVICE INFORMATION

To obtain service for your Etón product, first contact an Etón service representative at 1-800-872-2228 US, 1-800-637-1648 Canada or your respective country distributor in Europe (see enclosed list) for troubleshooting. Many common questions and problems can be resolved over the phone.

WARRANTY REGISTRATION

To ensure full warranty coverage or product updates, registration of your product should be completed as soon as possible after purchase or receipt. You may use one of the following options to register your product:

1. By visiting our website at <http://www.etoncorp.com>.
2. Mail in enclosed warranty card.
3. Mail your registration card or information to following address; include your name, full mailing address, phone number, email address, model purchased, date purchased, retail vendor name:

Etón Corporation
1015 Corporation Way
Palo Alto, CA 94303 USA

LIMITED WARRANTY

Retain the warranty information from your warranty card with your proof of purchase or the Limited Warranty information can also be viewed at www.etoncorp.com.

SERVICE FOR YOUR PRODUCT

To obtain service for your product, we recommend first contacting an Etón service representative at: 1-800-872-2228 US, 1-800-637-1648 Canada, (650) 903-3866 or customersvc@etoncorp.com for problem determination and trouble-shooting. If further service is required, the technical staff will instruct how to proceed based on whether the radio is still under warranty or needs non-warranty service.

WARRANTY – If your product is still in warranty and the Etón service representative determines warranty service is needed, a return authorization will be issued and instructions will be given. DO NOT ship your radio back without obtaining the return authorization.

NON-WARRANTY – If your product is no longer under warranty and requires service, the Etón service representative will refer you to the nearest repair facility that will best handle the repair.

For service outside North America, please refer to the distributor information included at time of purchase/receipt.